

# ROSY RINGS

## Candle making diy kit

### DIY KIT INCLUDES:

12 OZ GLASS VESSEL  
10 OZ COCONUT WAX BLEND  
.8 OZ FRAGRANCE OIL  
1 WICK  
2 POPSICLE STICKS

### YOU WILL NEED:

HOT GLUE GUN (OR SUPER GLUE)  
DOUBLE BOILER  
THERMOMETER  
WHISK

WATCH VIDEO TUTORIAL: [HTTPS://YOUTU.BE/ITTULNOU\\_LM](https://youtu.be/ittulnou_lm)

### DIRECTIONS

- 1 Using a hot glue gun, glue your wick onto the bottom center of the glass vessel. Alternatively, you can superglue it.
- 2 Unpeel your wax from the plastic cup. Discard the cup and place the wax into your double boiler. Allow the wax to melt on low for 10-15 minutes, whisking frequently.
- 3 Add the fragrance oil by simply pouring it into your melted wax and whisk for 30 seconds.  
*\*\*If concerned about using fragrance oil in your pot, you can use a non-food use container to mix the melted wax and fragrance oil together. Alternatively, you can skip this step and add the fragrance oil directly to your glass vessel following the next step.*
- 4 Let the melted wax cool for a few minutes. When the temperature on the thermometer reads 140 degrees, slowly pour the wax into the glass vessel. Hold the wick in place, but don't pull on it.  
*\*\*If adding the fragrance oil now, slowly pour the oil into your glass vessel and gently stir into the wax.*
- 5 To prevent your wick from swaying in the wax, you will need to secure it in place. Lay 2 popsicle sticks across the top of the container and sandwich the wick in between so that it stays centered while the wax hardens.
- 6 Allow the wax to set undisturbed for 4 hours at room temperature.

### CARE

To clean your pot, add 1 part vinegar to 3 parts hot water. Boil for 10 minutes and rinse clean. Alternatively, you can soak your pot in rubbing alcohol for 15 minutes. Rinse clean with soap and hot water.

